

# Novasonar GK / Short description of installation

Remark: This is a short description of the installation procedure. Installers and Contractors must prepare and adapt the material and procedures for the requirements of the specific applications!

Please note that this description provides only an overview of the installation process. Before installing the Novasonar GK-loudspeakers please make sure to also read the detailed recommendation for the non-visible installation of in-wall mounted ML Novasonar GK loudspeakers in dry mortarless construction.



## Step 1:

Prepare a cut-out within an existing gypsum plaster board planking or prepare a new gypsum plaster board planking, which offers a cut-out, allowing for a 5mm space between the edge of the Novasonar GK and the wall covering.



## Step 2:

In case transport braces were mounted on the backside of the speaker, please remove these and test the speaker to make sure that it was not damaged during the transportation. After the speaker has been successfully tested and has been found to be fully functional, connect the speaker cables!!

Attach the loudspeaker to the subconstruction.



## Step 3:

Screw the loudspeaker together with the metal profiles. Use preferably commercial screws for a fast mounting. The screws should not be further than 10 cm apart from each other.



## Step 4:

Fill the gaps according to the specifications of the manufacturer of the gypsum boards or the spackle.

Make sure, that the provided substructure of the gypsum plaster planking does not rattle because of the vibrations caused by the flat-pane loudspeaker. Pay close attention to the fact that no loose parts lay within or upon the substructure or are in any contact with it. Pay also attention to the fact, that the loudspeaker is not tangented by anything on its rear.



## Step 5:

Finished!